

Mooring Whip Instructions

Tools needed: (2) 5/16" wrenches

1. Fasten each of (2) mooring whip brackets to dock frame by sliding 2 sets of (2) 5/16" carriage bolts in both the upper and lower frame track to the appropriate location where mooring whips are to be located. (4 bolts per bracket, 8 bolts total per set).

2. Place mooring whip bracket over carriage bolts and secure with washers and hex nuts. *** Truss dock uses the 2 lower holes on the brackets and fastens to both the lower and upper track on truss dock.

3. Place mooring whip base over base mounting holes on mooring whip brackets and secure w/ (3) 5/16" hex bolts, washers, and nuts.

