

Bumper Instructions

Ultraguard Bumper Assembly Instructions
(Tools needed: 1/2" wrench)

1. Place Mounting Bracket in between Ultraguard Bumper and Bumper Post.
2. Connect Ultraguard Bumper to Bumper Post using 5/16" hex bolts, nuts, and washers. A washer will go on each side of the 2-3/4" long hex bolt. Tighten thoroughly.
3. Slide (4) 5/16" x 1-3/4" long carriage bolts into the track system at the location the Bumper Assembly is to be mounted.
4. Connect the Mounting Bracket in the Post/Bumper assembly to the Dock Frame track system using the carriage bolts installed in step 3 w/ 5/16" nuts and washers.
5. Adjust the Post/Bumper assembly up or down to the desired height and then tighten the (4) hex nuts on the Mounting Bracket to lock it in place.

*For vertical adjustment, it may be necessary to loosen the 2-3/4" long hex bolts that connect the Bumper to Post to get full vertical adjustment capabilities.

